

Cleaning Your Chromebook

1. Never spray any liquids directly onto the product.
2. Moisten a microfiber cloth with a mixture of 70% isopropyl alcohol / 30% water.
 - The cloth should be damp, but not dripping wet. Excess moisture should be removed if the cloth is wet before wiping the product.
 - Using any material other than a microfiber cloth could cause damage to your product.
3. Gently wipe the moistened cloth on the surfaces to be cleaned.
 - Do not allow any moisture to drip into areas like keyboards, display panels, etc. Moisture entering the inside of an electronic product can cause damage to the product.
 - Excessive wiping potentially could lead to damaging some surfaces.
4. When cleaning a display screen, carefully wipe in one direction, moving from the top of the display to the bottom.
5. Surfaces must be completely air-dried before turning the device on after cleaning.
 - No moisture should be visible on the surfaces of the product before it is powered on or plugged in.