




How to Reset Your Chromebook

Here is something to try if you are having battery issues with your Chromebooks (not powering on, not charging, etc.)

1. Turn off your Chromebook.
2. Press and hold Refresh  + tap Power .
3. When your Chromebook starts up, release Refresh .